

MRS4616A User Manual

Contents

Chapter 1	Introduction.....	3
1.1	overview.....	3
1.2	Physical Description.....	4
1.3	Technical Specifications.....	4
Chapter 2	Operation.....	6
2.1	Turning On the Unit.....	6
2.2	Device's Front Panel.....	6
2.3	Device's Rear Panel.....	7
2.4	Indicators.....	7
2.5	Turning Off the Unit.....	8
Chapter 3	Configuration.....	9
3.1	WEB Login.....	9
3.2	System configuration.....	9
Appendix A.....		15
Appendix B.....		16

Chapter 1 Introduction

1.1 overview

MRS4616A Series Gateway is a channelized Ethernet gateway for interconnecting TDM and packet-based networks. The Ethernet Gateway aggregates and switches Ethernet traffic into 8 or 16 channelized E1 circuits, each supporting up to 16 VCG. Ethernet traffic over channelized E1 lines is aggregated and transferred to the packet-switched network via the unit's Gigabit Ethernet ports. The encapsulation method support HDLC/PPP-BCP (RFC3518)/GFP-F.


The unit enables service providers to supply high capacity Ethernet services to remote locations. The units can also transparently connect corporate LANs utilizing existing E1 or T1 lines.

Applications

Typically deployed at a central location, MRS46xxA Series Gateway aggregates Ethernet Data received from other devices, thus completing a full access solution from the service provider's central site to the customer premises. The unit supports up to maximum 16VCG, allowing the connection of up to maximum 16 different customers per site.

Other typical applications include:

- Aggregation of Ethernet traffic over TDM wireless links
- Network management backhauling.



Features

- Up to 16 remote LANs over 8 or 16 E1 circuits aggregation
- Support 2047Bytes frames
- Support VLAN tagging and QinQ function
- Support HDLC/PPP-BCP (RFC3518)/GFP-F encapsulation
- Support E1 frame or un-frame application, and N*64K for framed mode
- Provide statistics for each E1 channel
- Support E1 proprietary ring protection

- Configure via CLI/Web/SNMP (v1/v2c/v3)
- Support software and firmware upgrade
- -48VDC/110/220VAC flexible redundant power inputs

Encapsulation

MRS4616A supports HDLC、PPP and GFP-F encapsulation
GFP (ITU-T G.8040, G.7041/Y.1303)

1.2 Physical Description

MRS4616A is a standalone or rack mountable device.



LEDs, interfaces, and control connectors are located on the front panel. For additional information, refer to Chapter 2.

1.3 Technical Specifications

E1 Interface

Number of Ports: 16

Compliance: G.703, G.704

Data Rate: 2.048 Mbps

Impedance: 120 Ω , balanced
75 Ω , unbalanced (via adapter cable)

Line Coding: HDB3

Connector: BNC, RJ-45

Line Protection: 15 KV ESD protections
6KV/42 Ω surge protection

Ethernet Interface

Number of Ports: Rj45: 2
SFP: 2

Type: 10/100 Mbps, auto-negotiation,
full/half duplex, flow control, MDI/MDX crossover

Compliance: Relevant sections of IEEE 802.3

Max Frame Size: 2047 bytes

Connector: RJ-45

Electrical Cable Type: SFP

Line Protection: Built-in 1.5 KV Magnetic Isolation Protection
6KV/42 Ω surge protection

Internal Bridge

Number of VLANs: Up to 16

Compliance: Relevant sections of 802.1Q and QinQ double tagging

LAN Table: Up to 2K MAC addresses (learned)

Management Ports

Console Port

Interface standard: RS-232

Connector: RJ-45

Baud Rate: 115.2 kbps

Power

Input Voltage:

AC: 100-240VAC, 50/60Hz

DC: -48VDC (36-72VDC)

AD: AC/DC dual power supply universal input

Power Consumption: <10 watts

Environmental Limits

Operating Temperature: 0 to 50° C (32 to 122°F)

Storage Temperature: -40 to 70° C (-40 to 158°F)

Humidity: 10 to 95% (non-condensing)

Physical

Housing: Metal

Height: 43.5 mm (1.7 in)

Width: 430.0 mm (16.9 in)

Depth: 200.0 mm (7.9 in)

Weight: 2.7 kg (5.9 lb)

Standard 1U and 19-inch rack mount size

Chapter 2 Operation

This chapter:

- Explains how to power MRS4616A up and down.
- Describes the device's panel
- Provides a detailed description of the front panel controls and indicators and their functions.

2.1 Turning On the Unit

- To turn on the unit:
- Connect the power cord to the mains.

The PWR indicator turns on and remains on as long as MRS4616A receives power.

Once installed, MRS4616A requires no operator attention, except for occasionally monitoring the front panel indicators. Intervention is only required when the unit must be configured to its operational requirements, or when diagnostic tests are performed.

2.2 Device's Front Panel

Figure 3-1 lists the front panel of different specifications

Figure 2-1 Front Panel

Figure 2-1-1 E1 120Ω 2 optical 2 Ethernet




Figure 2-1-2 E1 120Ω 4 Ethernet




Figure 2-1-3 E1 75Ω 2 optical 2 Ethernet





Figure 2-1-4 E1 75Ω 2 Ethernet



2.2.1 Front Panel Interface Description

The front panel has four Ethernet interfaces or two Ethernet interfaces and two SFP optical interface, a Console port, 8/16 of the E1 (BNC or RJ45) interface and RESET button.

Ethernet interface

Ethernet interface using with Lamp

Reset

Used to restore the factory default configuration,.

The system during normal operation, if you hold down the Reset button more than 3 seconds, the system will restore the factory default configuration and restart.

E1 Interface

Q9 (75Ω), RJ45 (120Ω)

Console Port

Provide a series of Config and CLI command device configuration management. Local configuration through the Console port

2.3 Device’s Rear Panel

Different specifications of the rear panel are the same.

Figure 2-2 Rear Panel



2.3.1 Power

Two power interface, AC220V or DC-48V input

AC220V: POWER connect 'L', RETURN then 'N';

DC-48V: POWER connect to the cathode, RETURN then negative.

2.4 Indicators

The unit's LEDs are located on the front panel. Table 3-1 lists the functions of the LED indicators.

Ethernet indicator diagram




Table 2-1. LEDs and Controls

Name	Colors	Functions
POWER	Green	On- Unit is powered
		Off- Unit is off
FB2	GREEN	On- Fiber connected
		Flash- Device transmitting data
		Off- Fiber disconnected
FB1	GREEN	On- Fiber connected
		Flash- Device transmitting data
		Off- Fiber disconnected
SYS	YELLOW	Flash- System is working
		On- System is abnormal
		Off- System is booting abnormally
LOS1~16	RED	On- Channel alarm detected
		Off- no alarm currently detected
SPD1~4	GREEN	On- Ethernet Speed is 100M

		Off- Ethernet Speed is 10M
ACT1~4	YELLOW	Flash- Device is transmitting data.
		On- Network is established
		Off- Ethernet disconnected

2.5 Turning Off the Unit

- To turn off the unit:
 - Remove the power cord from the power source.

Chapter 3 Configuration

3.1 WEB Login

Use IE browser as an example. Open the web browser, input the default IP address in the address bar: 192.168.0.168.

As below the login dialog, input the right username and password. The username and password is all “root” .

3.2 System configuration

3.2.1 System information

✧ Software Version.

Item	Setting
▶ Software Version	1.03
▶ FirmWare Version	1.02
▶ Running Time	0 Hour 1 Min 42 Sec
▶ MAC Address	A4:C2:AB:02:8F:75
▶ System Name	<input type="text"/>
▶ Save Config	...
▶ System Reboot	...

Config Refresh

✧ Firmware Version.

✧ Running Time.

✧ MAC Address.

✧ System Name.

✧ System Reboot.

3.2.2 Network configuration

✧ IP Address: 192.168.0.168.

Here you can change the system Network Config. After you have changed the IP address, you need to change also the host IP address in you Internet browser to re-connect to target. Make changes with care or you may permanently lose a connection until next hardware reset.

Item	Setting
▶ IP Address	192.168.0.168
▶ Net Mask	255.255.0.0
▶ Default Gateway	192.168.0.1

Config Refresh

✧ Net Mask.

✧ Default Gateway.

3.2.3 Password configuration

- System Config
 - System Info
 - Network Config
 - Password Config
 - SNMP Config
- Service Config
- Alarm & Static
- System Upgrade

Password Config

This page allows you to change the CLI and WEB password for the user root. After you change the password, you need to re-login with the new password.

Item	Setting
Authentication	Enabled
Old Password	<input type="password"/>
New Password	<input type="password"/>
Retype Password	<input type="password"/>

Config Refresh

User can change password on this page and re-login use the new password.

3.2.4 SNMP configuration

- System Config
 - System Info
 - Network Config
 - Password Config
 - SNMP Config
- Service Config
- Alarm & Static
- System Upgrade

SNMP Config

Item	Setting
Trap Target Host 1	<input type="text" value="0.0.0.0"/>
Trap Target Host 2	<input type="text" value="0.0.0.0"/>
Read Community	<input type="password" value="*****"/>
Write Community	<input type="password" value="*****"/>

Config Refresh

Test SNMP function in this web page.

3.2.5 Global Configuration

- System Config
 - System Info
 - Network Config
 - Password Config
 - SNMP Config
 - Global Config
 - Channel Config
 - Ethernet Config
 - E1 Test
 - Vlan Table
- Service Config
- Alarm & Static
- System Upgrade

Global Config

Item	Setting
Dot1Q Vlan Enable	Disable
Admin Vlan(0-4094)	<input type="text" value="0"/>
QinQ Ether Type	0x88A8
QinQ Ether Pvid(1-4094)	<input type="text" value="0"/>
QinQ Enable	Disable
Port Isolation	Channel Isolation
E1 Clock Source(0:Internal,1-16:E1)	<input type="text" value="0"/>

Config Refresh

✧ Dot1Q Vlan Enable: Vlan&QinQ function enable.

①Enable②Disable, The default configuration is Disable.

✧ Admin Vlan: User interface VLAN. The default configuration If Dot1Q Vlan Enable is set to Enable, then that becomes closed, you need this first configuration is 0 or WEB page will not be able to enter.

✧ QinQ Enable: Double Vlan enable. ①Enable②Disable

✧ QinQ Ether Type: Double Vlan type setup.

✧ E1 QinQ Pvid: Double VLAN value.

✧ Ethernet Isolation

3.2.6 Channel configuration

The screenshot shows a web-based configuration interface for a network device. On the left is a navigation menu with categories like System Config, Service Config, and Alarm & Statistics. The main area is titled 'Channel Config' and contains a list of items with their corresponding settings. Below this is a summary table.

Item	Setting
Channel ID	1
E1 List Bind(eg:1,3-5)	1-16
Encapsulation Protocol	GFP
Frame Mode	Frame
Time Slot(eg:1,3-5)	1-31
GFP TxScramble	Both
GFP RxScramble	Both
GFP LCAS	Enable
GFP FCS	Disable
GFP Ext Header	Null Header
Vlan Mode	Access
PVID(1-4094)	0
Loop Detection	Enable

Ch	E1 List	Protocol	Vlan Mode	Pvid	PPP Status	Loop
1	1-16	GFP	-	0	-	OK

✧ Channel ID: Choice of channel number, ranging from 1 to 16. The default is 1 channel.

✧ E1 List Bind (eg: 1, 3-5): The corresponding channel E1 number list, you can choose any 1-16 a few road E1. The default configuration for 1-16.

✧ Encapsulation Protocol: E1 encapsulation mode, there are three modes of GFP / HDLC / PPP. The default is GFP mode.

✧ Frame Mode: Frame mode selection, there are two modes of framed and unframed. The default is framed.

✧ Time Slot (eg: 1, 3-5): In framing mode, the choice of the number of time slots, ranging from 1 to 31. Can be arbitrarily chosen, the default configuration of 1-31.

✧ GFP TX Scramble: GFP sent scrambling code, the default is Both.

✧ GFP Rx Scramble: GFP receive scrambling code, the default is Both.

✧ GFP LCAS: GFP LCAS enabled, the default is Enable

✧ GFP FCS: GFP frame check, the default is Disable.

✧ GFP Ext Header: involve Null-Header and Linear-Framer, the default is Null-Header.

✧ Vlan Mode: vlan mode, involve access/Trunk.

✧ PVID(1-4094): Port Vlan id, Divided Vlan network identification number, the default is 1.

✧ Loop Detection: E1 loopback detection. the default is Enable.

3.2.7 Ethernet configuration

✧ Config Mode: Set the work mode of the Ethernet

①auto②half-10③full-10④half-100⑤full-100

✧ Ethernet rate-limiting function ①Egress Rate Limit transmit

②Ingress Rate Limit receive: The default configuration is 0.

3.2.8 E1 Test

Open this web page, set the E1 Index same with self-loop port number, Pattern Text choice enable and click Config to check the E1 circuit is normal or not.

3.2.9 Vlan Table

Support 16 vlan tables:

✧ Vlan table will be effective when 'Dot1Q Vlan' function in 'System Config' page is enabling.

✧ 0 delete vlan, management vlan can't be deleted.

✧ If corresponding vlan is deleted, pvid need be reset.

3.2.10 E1 alarm

This page shows the E1 alarm.

E1 Alarm														
E1	LOS	AIS	LOF	LOMF	CRC	RAI	LOOP	GFP LOMF1	GFP LOMF2	GFP CRC8	GFP DNU	GFP RSync		
1	Err	OK	Err	OK	OK	OK	OK	Err	Err	OK	OK	OK		
2	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
3	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
4	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
5	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
6	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
7	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
8	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
9	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
10	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
11	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
12	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
13	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
14	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
15	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		
16	Err	OK	Err	OK	OK	OK	OK	OK	OK	OK	OK	OK		

Refresh

3.2.11 Ethernet Statistics

Ethernet statistics will automatically refresh every 10s.

Ethernet Statistics														
The page will auto refresh every 10 seconds.														
Port	TX Pkts		RX Pkts		RX Drop		RX CRC		Fragment					
Eth 1	0		0		0		0		0					
Eth 2	482		833		0		0		0					
Eth 3	0		0		0		0		0					
Eth 4	0		0		0		0		0					
E1 Total	502		0		0		0		0					

Counter Reset Refresh

3.2.12 Channel statistics

Channel statistics will automatically refresh every 10s.

Channel Statistics														
The page will auto refresh every 10 seconds.														
Port	TX Pkts		RX Pkts		Err Pkts									
Ch 1	0		0		0									
Eth Total	0		525		0									

Counter Reset Refresh

3.2.13 System update

Update the software and firmware in the page, the software must be named as *.bin and firmware must be named as *.rbf.

System Config

- System Info
- Network Config
- Password Config
- SNMP Config

Service Config

- Global Config
- Channel Config
- Ethernet Config
- E1 Test
- Vlan Table

Alarm & Statistic

- E1 Alarm
- Ethernet Stat.
- Channel Stat.

System Upgrade

System Upgrade

Upgrade Status: **Not Start,Please select uprade type first.**

Step 1: Select Upgrade Type.

Step 2: Select a file from local PC to upgrade.

Step 3: Reboot after upgrade.

Appendix A

Connector Wiring

A.1 Ethernet Connector

The 10/100BaseT Ethernet electrical interface is an 8-pin RJ-45 connector, wired according to Table A-1.

Table A-1. 10/100BaseTX Ethernet Connector Pinouts	
Pin	Function
1	Tx+
2	Tx-
3	Rx+
4, 5	-
6	Rx-
7, 8	-

A.2 E1 Connector

The E1 electrical interface is an 8-pin RJ-45 connector, wired according to Table A-2.

Table A-2. E1 Connector Pinouts	
Pin	Function
1	Rx+
2	Rx-
3	NC
4	Tx+
5	Tx-
6	NC
7	NC
8	NC

A.3 Console

The Console interface is an 8-pin RJ-45 connector, wired according to Table A-3.

Table A-3. Console Pinouts	
Pin	Function
3	Txd (TD)
6	Rxd (RD)
4, 5	Ground (GND)

Appendix B

Warranty Card

Our company is committed to provide users with the following terms:

1. Warranty service

1) Within the charge free warranty term (within 12 months since the purchase of the product), damaged parts can be exchanged free of charge and maintenance charges will be free in the conditions that the device is considered to be malfunctioned in normal service by our company.

2) Within the charged warranty term (more than 12 months and within 36 months since the purchase of the product), damaged parts will be charged for corresponding cost with free maintenance service in the conditions that the device is considered to be malfunctioned in normal service by our company.

2. Users can not enjoy warranty service with the following cases and corresponding cost of damaged parts replacing and maintenance service will be charged

(1) Exceed 36 months since the purchase of the product

(2) Can't provide certificate of purchasing date, and serial No. of product shows that ex-works term has exceeded 36 months;

(3) Include but not limit to the abnormal service conditions such as violent knocking, extrusion, drop, liquid immersion that cause damages;

(4) Fragile label on the device is damaged;

(5) User disassembles this product himself

(6) Force majeure that leads to product damage, such as earthquake, flooding and lightening stroke;

3. The newly installed parts after maintenance will be repaired free of charge within 12 months since the installation date.

4. When malfunction occurs, users can choose to send it to our company to receive maintenance service or to post it to maintenance points of our company all over the country to be repaired.

5. Our company does not undertake any responsibilities for losses caused by abnormal operation; for losses really caused by product itself, including but not limited to all direct or indirect losses due to data loss, our company will only undertake responsibilities within the selling price of products.

Repair and Maintenance Record

Product Name: MRS 4616A		Device No.:
Maintenance date		No. of Service Bill
1		
2		
3		
4		
5		